


SmartGo Instructions

A. LOCKING PARTS



B. SET YOUR OWN COMBINATION

Factory preset at 0-0-0

1. Turn dials 0-0-0 to align with the small circles and remove the cable at dials end.



2. Use a pointed object to press reset button to the end as arrow directed. Hold it until completing the next step.



3. Set the dials to your personal code.
* Please write down and keep your code in a safe place.

□ - □ - □



C. HOW TO USE THE USER KEY

1. Insert the user key and there is a tenon when turning counter clockwise 90 degree.



2. Remove the cable from cylinder end as the arrow directed.



3. Insert the cable to the lock body, turn the key clockwise 90 degree, pull out the key then the lock is locked.




info@smartgo.club
www.smartgo.club

© SmartGo Worldwide Inc.
f smartgoclub

SmartGo 使用說明書

A. 各部名稱



B. 密碼設定方式

出廠密碼設定000

1. 轉動字輪000至對號點位置，取下字輪端鋼索即開鎖。



2. 使用筆或尖物，依箭頭方向持續壓變號鈕到底，直到完成步驟3。



3. 轉動字輪設置您的新密碼。
□ - □ - □



C. 鑰匙使用方式

1. 插入鑰匙逆時鐘旋轉90°會有卡點。



2. 如圖將鋼索從鎖心端取下即開鎖。



3. 如圖將鋼索裝入鎖座。順時鐘旋轉90°並將鑰匙抽出即上鎖。

