




POKEBUDDY2

Pokefi Battery Charger

QUICK START GUIDE

SmartGo.club




Specifications


- Input: 5.0V / 1A-2A
- Output: 4.35V / 0.9A-1.7A
- Weight: 18g

⚠️ Cautions

- The charger is restricted to charging the Pokefi battery SY300-1 only. Never use the charger with other types of batteries as this could result in damages.
- Never leave the charger unattended when it is connected to power. If any malfunction is found, please unplug from the power source immediately.
- Never charge any battery having evidence of leakage, expansion/swelling/distortion, as doing so may lead to charger short-circuit or even explosion.
- Do not expose the device to direct sunlight, heating devices, open flames; avoid extremely high or extremely low ambient temperatures and sudden temperature changes.
- Do not short-circuit slots or other parts of the charger.
- Do not allow metal wires or other conductive material into the charger.
- Do not overcharge or over-discharge batteries. Recharge drained batteries as soon as possible.
- Remove the battery and unplug the charging unit from the power source when not in use.
- Do not misuse in any way. Use indoors for intended purpose and function only.



A. Connecting: Plug one end of the included Micro USB cable into the input port and the other end into a power supply (adapter, PC or other standard USB output port). Upon powering up, the LED will light up.



C. Charging Progress: The Red LED light indicates charging in progress. When the battery is fully charged, the LED light will turn Blue.

B. Inserting Battery: Insert the Pokefi battery as instructed (make sure both metal points are firmly contacted). The LED light should be in Red before the battery is fully charged. An incorrectly inserted battery will prevent it from functioning.

SG-DTC1402

www.mypokefi.com

Customer Service
service@everlong.biz
©SmartGo Worldwide Inc.